

M-Audio Support Documentation: Setting Up Your Delta Card To Work With Logic (EASI)

1. Go to **Audio** menu and then select **Audio Preferences**.



2. Check that nothing is checked in any of the checkboxes on the **Audio Driver Tab**.

3. From here, make sure that *M Audio Delta EASi* is selected.

4. PC AV must be checked at the top left as shown.

5. Towards the bottom, put a check in the **20/24-bit Recording** and **Monitoring** checkboxes.

6. Click **Close** when you're finished.

7. Now from the **Arrange window**, double-click on an **Audio track** and you will get into the **mixer section** of Logic.



8. From **Audio track1** you will need to decide whether you are going to record a *mono* track or *stereo* on the **O** next to **Rec.** **O** represents mono, while **OO** represents stereo.

This setting is located at the bottom of each fader.



9. Now you will need to direct the input signal where it says **Input**. Click and hold on the **Input** button and the Input Menu will appear.

You can now press on the **Rec** button and it will prompt you to where you want to save the audio files, select a desired location and hit **OK**.

10. Close the *monitor window* and you are ready to record.



M-AUDIO

propellerhead

ableton

G

arKaos

copyright 1988-2003 midiman inc. all rights reserved.